



LUVANTIX Corp.
22 Quail Run
Warren, NJ 07059
TEL 732-271-0350
FAX 732-348-9496

TECHNICAL DATA SHEET

Polymer Cladding, PC 363L AP

CONTENTS

- A. MATERIAL DESCRIPTION**

- B. MATERIAL PROPERTIES**
 - 1. Liquid**
 - 2. Cured**

- C. APPENDIX**
 - 1. Test Equipment**
 - 2. Test Methods**

A. MATERIAL DESCRIPTION

UVF PC-363L AP coating is a radiation-curable acrylate useful for polymer cladding making processes. UVF PC-363L AP coating has suitable glass transition temperature, rapid cure property, non-yellowing, thermal resistance, high oxidative and hydrolytic (moisture) stability, which are required by optical fiber industry applications.

1. CURING CONDITION

Minimum UV dose of UVF PC-363L AP for complete cure is 1000 mJ/cm² under a nitrogen environment. However, the minimum dosage is heavily dependent upon the thickness of the PC layer.

2. STORAGE

UVF PC-363L AP polymer cladding coating can polymerize under improper storage conditions. Store materials away from direct sunlight and presence of oxidizing agents and free radicals. Storage temperature range is between 15°C to 27°C.

3. PRECAUTION

UVP PC-363L AP polymer cladding coating materials can cause skin and eye irritation after contact. Therefore, avoid direct contact with these materials. If contact occurs, immediately rinse affected areas copiously with water.

4. NOTES

The information contained herein is believed to be reliable but is not to be taken as representation, warranty or guarantee and customers are urged to make their own tests.

B. MATERIAL PROPERTIES

1. LIQUID

Viscosity	at 25 °C	5800 cPs ± 600
Density	at 24 °C	1.50 ~ 1.55 g·cm ⁻³
Refractive Index	at 25°C, 589 nm	1.358 ± 0.005

2. CURED

Refractive Index	at 852 nm	1.363 ± 0.005
Secant Modulus	At 2.5% Strain	20 ~ 25 Mpa
Tensile Strength	at Break	2.0 ~ 4.0 Mpa
Elongation	at Break	30 ~ 70 %
Shrinkage	on Cure	~ 4.9 %

The information contained herein is believed to be reliable but is not to be taken as a representation, warranty or Guarantee. Customers are urged to perform their own process and QC tests.

C. APPENDIX

1. TEST EQUIPMENT

	Test Equipment
Viscosity (cPs)	Brookfield DV II+ or DV III+
Refractive Index (uncured)	Abbe refractometer
Density (g/cm ³)	Pycnometer
Refractive Index (cured)	Prism Coupler / Abbe refractometer
Shrinkage On Cure	Pycnometer
Secant Modulus (kgf/mm ²)	Instron 4443 UTM
Elongation (%)	Instron 4443 UTM
Tensile Strength (kgf/mm ²)	Instron 4443 UTM

2. TEST METHODS

Viscosity (cPs)	ASTM D-1084 Method B	V = fs V=Viscosity of sample in centipoises f=Scale factor furnished with instrument s = Scale reading of viscometer
Refractive Index	ASTM D 542 – 50	
Density (g/cm ³)	ASTM 1475	D = (W – w)/V V =Volume of container(mL) W = Weight of the filled container w = Weight of the empty container D = Density (g/mL)
Shrinkage On Cure	ASTM D-792	X = (a x d) / (b + a – m) % Shrinkage = (X-d)/d a = Sample Weight d = Specific Gravity of Uncured Sample b = Weight of Pycnometer and water m = Weight of Water and Sample in Pycnometer e = Weight of Pycnometer
Secant Modulus (kgf/mm ²)	ASTM D-638	
Elongation (%)	ASTM D-638	(L – L₀) / L₀ X 100 L ₀ = Length of initial L=Length at break point
Tensile Strength (kgf/mm ²)	ASTM D-638	P/ (T X W) T = Film Thickness, P= Tensile pull to rupture W= Width of Film

Revised Date : 12.Mar.,2014

The Term of Validity : 12: Mar,2014 ~ 11. Mar.2015